

## SC-501 Operating Instructions

### TO TIME SINGLE EVENTS

Press "A" to START timing. "RUN" appears  
Press "A" to STOP timing. "STOP" appears

After reviewing the time reading, press "B" to RESET timer to all zeros.

You may take as many consecutive single event times as necessary by repeating this procedure. Single event times can be taken in either LAP or SPLIT modes.

Please notice that the front two pushbuttons DO NOT provide any functions.



### LAP and SPLIT TIMES

The LAP mode records and displays the **INTERVAL** of time from the previous reading(s). The **SPLIT** mode shows the **ACCUMULATED** time from the start of the event.

While the timer is RESET to all zeros, select the LAP or SPLIT timing mode by pressing "B"

Press

Press "A" to START timing. "RUN" appears.

PRESS "B" to take a LAP or SPLIT reading. The time will appear frozen on the display for 15 seconds. After 15 seconds, the time display will automatically release to show the current running time.

You may take as many LAP or SPLIT readings as necessary by pressing "B".

Press "A" to STOP timing and press "B" to RESET to all zeros.